
Kodak EasyShare V550 zoom digital camera



User's guide

www.kodak.com

For interactive tutorials, www.kodak.com/go/howto

For help with your camera, www.kodak.com/go/v550support



Eastman Kodak Company
Rochester, New York 14650


© Eastman Kodak Company, 2005


All screen images are simulated.

Kodak and EasyShare are trademarks of Eastman Kodak Company.
Schneider-Kreuznach and Xenar are trademarks of Jos. Schneider Optische Werke
GmbH used under license by Eastman Kodak Company.


P/N 4J3440

Front view



- | | | | |
|---|----------------------------------|----|--|
| 1 | Shutter button | 8 | Auto mode button |
| 2 | Flash button | 9 | Viewfinder |
| 3 | On/Off | 10 | Light sensor |
| 4 | Video/AF Assist/Self-timer light | 11 | Lens |
| 5 | Video mode button | 12 | DC-In (5V)  |
| 6 | Scene (SCN) mode button | 13 | Grip |
| 7 | Portrait mode button | 14 | Flash |
| | | 15 | Microphone |

Back view




- | | |
|--|-------------------------------------|
| 1 LCD | 11 Battery compartment |
| 2 Wide angle/Telephoto button | 12 Slot for optional SD or MMC card |
| 3 LCD/Info button | 13 Dock connector |
| 4 Auto/Favorites switch | 14 Tripod socket |
| 5 Strap post | 15 Speaker |
| 6 USB, A/V Out | 16 Share button |
| 7  | 17 Review button |
| 8 OK button | 18 Menu button |
| 9 Battery lock | 19 Delete button |
| 10 Close-up/Landscape button | 20 Viewfinder |
| | 21 Ready light |

Table of contents


1	Setting up your camera	1
	Attaching the strap	1
	Loading the battery	1
	Charging the battery	2
	Turning on the camera	3
	Setting the date/time, first time	3
	Storing pictures on an SD or MMC card	4
2	Taking pictures and videos	5
	Taking a picture	5
	Reviewing pictures and videos	9
	Deleting pictures and videos	11
3	Transferring and printing pictures	12
	Installing the software	12
	Transferring pictures with the photo frame dock 2	13
	Transferring pictures with the USB cable	13
	Also available for transferring	14
	Printing pictures	14
	Dock compatibility for your camera	17
4	Doing more with your camera	18
	Using optical zoom	18
	Changing the flash settings	19
	Picture-taking modes	20
	Running a slide show	23
	Cropping pictures	25
	Making pictures from a video	26
	Viewing picture/video information	26
	Using the histogram to view picture brightness	27
	Using exposure compensation to adjust picture brightness	27

Copying pictures and videos	27
Changing picture-taking settings	28
Customizing your camera	33
Pre-tagging for album names	35
Sharing your pictures	37
5 Troubleshooting	42
Camera problems	42
Computer/connectivity problems	44
Picture quality problems	44
Direct printing (PictBridge enabled printer) problems	46
6 Getting help	47
Helpful links	47
Telephone customer support	48
7 Appendix	49
Camera specifications	49
Flash settings in each mode	51
Storage capacities	53
Important safety instructions	54
Battery life	55
Upgrading your software and firmware	56
Additional care and maintenance	56
Limited Warranty	57
Regulatory compliance	59


1

Setting up your camera

Attaching the strap



Loading the battery




For information on replacing batteries and extending battery life, see [page 55](#).

Charging the battery

Charge the battery until all 4 lights on the camera top are lit (approximately 3 hours).

EasyShare photo frame dock 2


(May be sold separately.)



5-volt AC adapter


(included with your camera)

IMPORTANT: Use this AC adapter to charge the battery and to power the EasyShare photo frame dock 2.




EasyShare printer dock series 3 or EasyShare camera dock series 3


(May be sold separately. For dock compatibility, see [page 17](#).)



Turning on the camera




Setting the date/time, first time



Storing pictures on an SD or MMC card

Your camera has 32 MB of internal memory. You can purchase an SD or MMC card to conveniently store more pictures and videos.

NOTE: We recommend Kodak SD or MMC cards. When using the card for the first time, format it in this camera before taking pictures (see [Format](#), page 35).



CAUTION:


A card can only be inserted one way; forcing it may cause damage. Inserting or removing a card when the ready light is blinking may damage the pictures, the card, or the camera.

See [page 53](#) for storage capacities. Purchase SD or MMC cards at a dealer of Kodak products or www.kodak.com/go/v550accessories.


2

Taking pictures and videos

Taking a picture




Taking a video



Reviewing the picture or video just taken

After you take a picture or video, the LCD displays a quickview for approximately 5 seconds. If you press no buttons, the picture/video is saved.



To view pictures and videos anytime, see [page 9](#).

Understanding the blur warning icons

If the feature is turned on (see [Blur Warning, page 35](#)), a picture blur warning icon  is displayed during quickview.


Green—Picture is sharp enough for an acceptable 4 x 6-inch (10 x 15 cm) print.

Yellow—Picture may be sharp enough for an acceptable 4 x 6-inch (10 x 15 cm) print or sharpness is not determined. (You may want to view on a computer monitor before printing.)

Red—Picture is not sharp enough for an acceptable 4 x 6-inch (10 x 15 cm) print.

White—Printability is still being determined.

Understanding the picture-taking icons




Using the auto-focus framing marks (for pictures)

When using the LCD as a viewfinder, framing marks indicate the camera focus area. The camera attempts to focus on foreground subjects, even if the subjects are not centered in the scene.

- 1 Press the Shutter button **halfway**.

When the framing marks turn green, focus is accomplished.


<p>Framing marks</p> 	<table border="1"><tr><td data-bbox="549 373 683 434">[]</td><td data-bbox="683 373 944 434">Center focus</td></tr><tr><td data-bbox="549 434 683 494">[]</td><td data-bbox="683 434 944 494">Center wide focus</td></tr><tr><td data-bbox="549 494 683 555">[]</td><td data-bbox="683 494 944 555">Side focus</td></tr><tr><td data-bbox="549 555 683 615">[]</td><td data-bbox="683 555 944 615">Center and side focus</td></tr><tr><td data-bbox="549 615 683 792">[] []</td><td data-bbox="683 615 944 792">Left and right focus</td></tr></table>	[]	Center focus	[]	Center wide focus	[]	Side focus	[]	Center and side focus	[] []	Left and right focus
[]	Center focus										
[]	Center wide focus										
[]	Side focus										
[]	Center and side focus										
[] []	Left and right focus										

- 2 If the camera is not focusing on the desired subject (or if the framing marks disappear), release the Shutter button and recompose the scene.
- 3 Press the Shutter button **completely down** to take the picture.

NOTE: Framing marks do not appear in Landscape or Video mode. When you use Focus Zone and set Center Zone ([page 31](#)), the framing marks are fixed at Center Wide.


Reviewing pictures and videos

Press the Review button to view and work with your pictures and videos.




NOTE: To learn how to choose and view your favorite pictures, see [page 39](#). To save battery power, use an EasyShare photo frame dock 2. (See www.kodak.com/go/v550accessories.)


Magnifying a picture during review



Viewing multi-up (thumbnails) during review



Understanding the review icons




For details on blur warnings, see [page 7](#).

Deleting pictures and videos

- 1 Press the Review button.
- 2 Press ◀/▶ for previous/next.
- 3 Press the Delete button.
- 4 Follow the screen prompts.
NOTE: To delete protected pictures and videos, remove protection before deleting.
- 5 Press the Menu button to exit the menu.

Protecting pictures and videos from deletion

- 1 Press the Review button.
- 2 Press ◀/▶ for previous/next.
- 3 Press the Menu button.
- 4 Press ▲/▼ to highlight Protect, then press the OK button.
NOTE: The picture or video is protected and cannot be deleted. The Protect icon  appears with the protected picture or video.
- 5 Press the Menu button to exit the menu.



CAUTION:

Formatting internal memory or an SD or MMC card deletes all (including protected) pictures and videos. (Formatting internal memory also deletes email addresses, album names, and favorites. To restore them, see EasyShare software Help.)

3

Transferring and printing pictures



CAUTION:

Install Kodak EasyShare software *before* connecting an EasyShare camera or dock to the computer. Failure to do so may cause the software to load incorrectly.

Installing the software


- 1 Close all software applications that are open on your computer (including anti-virus software).
- 2 Place the Kodak EasyShare software CD into the CD-ROM drive.
- 3 Load the software:
 - Windows OS**—if the install window does not appear, choose Run from the Start menu and type **d:\setup.exe** where **d** is the drive letter that contains the CD.
 - Mac OS X**—double-click the CD icon on the desktop, then click the Install icon.
- 4 Follow the on-screen instructions to install the software.
 - Windows OS**—select Complete to automatically install the most commonly used applications. Select Custom to choose the applications you wish to install.
 - Mac OS X**—follow the on-screen instructions.

NOTE: When prompted, register your camera and software. Registering lets you sign up for information that keeps your system up-to-date. To register later, see www.kodak.com/go/register.

For information on the software applications included on the Kodak EasyShare software CD, click the Help button in EasyShare software.


Transferring pictures with the photo frame dock 2

Your package may include an EasyShare photo frame dock 2. (To purchase accessories, see www.kodak.com/go/v550accessories.)



Transferring pictures with the USB cable

If your package did not include an EasyShare photo frame dock 2, use the USB cable to transfer pictures.



NOTE: Visit www.kodak.com/go/howto for an online tutorial on connecting.

Also available for transferring

You can also use these Kodak products to transfer your pictures and videos.

- Kodak EasyShare camera dock series 3 or printer dock series 3 (see [page 17](#))
- Kodak multi-card reader, Kodak SD multimedia card reader-writer

Purchase these and other accessories at a dealer of Kodak products or www.kodak.com/go/v550accessories.

Printing pictures

Printing with an EasyShare printer dock series 3

Dock your camera to the Kodak EasyShare printer dock series 3 and print directly—with or without a computer. Purchase this and other accessories at a dealer of Kodak products or www.kodak.com/go/v550accessories.

For dock compatibility, see [page 17](#).

Direct printing with a PictBridge enabled printer

Your camera is compatible with PictBridge technology, so you can print directly to PictBridge enabled printers. You need:

- Camera with fully charged batteries
- PictBridge enabled printer
- USB cable included with your camera

Connecting the camera to a PictBridge enabled printer

- 1 Turn off the camera and printer.
- 2 Connect the appropriate USB cable from the camera to the printer. See your printer user guide for details or www.kodak.com/go/v550accessories to order cables.

Printing from a PictBridge enabled printer

- 1 Turn on the printer. Turn on the camera.

The PictBridge logo is displayed, followed by the current picture and menu. (If no pictures are found, a message is displayed.) If the menu interface turns off, press any button to redisplay it.

- 2 Press ▲/▼ to choose a printing option, then press the OK button.

Current Picture—Press ◀/▶ to choose a picture. Choose the number of copies.

Tagged Pictures—If your printer is capable, print pictures that you tagged for printing and choose a print size.

Index Print—Print thumbnails of all pictures. (This option requires one or more sheets of paper.) If the printer is capable, choose a print size.

All Pictures—Print all pictures in internal memory, on a card, or in Favorites. Choose the number of copies.

Image Storage—Access internal memory, a card, or Favorites.

NOTE: During direct printing, pictures are not permanently transferred or saved to the computer or printer. To transfer pictures to your computer, see [page 12](#). In Favorites mode, the current favorite picture is displayed.

Disconnecting the camera from a PictBridge enabled printer

- 1 Turn off the camera and printer.
- 2 Disconnect the USB cable from the camera and the printer.

Using a printer that is not PictBridge enabled

For details on printing pictures from your computer, click the Help button in EasyShare software.

Ordering prints online



Kodak EasyShare gallery (www.kodakgallery.com) is one of the many online print services offered in EasyShare software. You can easily:

- Upload your pictures.
- Edit, enhance, and add borders to your pictures.
- Store pictures, and share them with family and friends.
- Order high-quality prints, photo greeting cards, frames, and albums—and have them delivered to your door.

Printing from an optional SD or MMC card

- Automatically print tagged pictures when you insert your card into a printer with an SD/MMC card slot. See your printer user's guide for details.
- Make prints at an SD/MMC card-capable Kodak picture maker. (Contact a location prior to visiting. See www.kodak.com/go/picturemaker.)
- Take the card to your local photo retailer for professional printing.

Dock compatibility for your camera

Dock	Docking configuration
<ul style="list-style-type: none"> ■ EasyShare photo frame dock 2 	See Transferring pictures with the photo frame dock 2 , page 13.
<ul style="list-style-type: none"> ■ Kodak EasyShare printer dock series 3 and EasyShare camera dock series 3 	 <p>Custom dock insert</p> <p>Dock</p>
Kodak EasyShare: <ul style="list-style-type: none"> ■ printer dock ■ printer dock plus ■ printer dock 6000 ■ camera dock 6000 	 <p>Custom dock insert</p> <p>Kodak dock adapter D-22</p> <p>Dock</p>
Other docks: <ul style="list-style-type: none"> ■ printer dock 4000 ■ camera dock II ■ LS420, LS443 camera dock 	Not compatible


Purchase camera docks, printer docks, and other accessories at a dealer of Kodak products or www.kodak.com/go/v550accessories.

4

Doing more with your camera

Using optical zoom

Use optical zoom to get up to 3X closer to your subject.



- 1 Use the viewfinder or LCD to frame your subject.
- 2 Press Telephoto (T) to zoom in. Press Wide Angle (W) to zoom out.

If the LCD is on, the zoom indicator shows zoom status.

- 3 Take the picture or video.

NOTE: For focus ranges, see [page 49](#).


Using digital zoom

Use digital zoom in any Still mode to get up to 4X magnification beyond optical zoom.

- 1 Press Telephoto (T) to the optical zoom limit (3X). Release the button, then press it again.
- 2 Take the picture or video.





NOTE: You cannot use digital zoom for video recording. You may notice decreased image quality when using digital zoom. The slider on the zoom indicator turns red when the picture quality reaches the limit for an acceptable 4 x 6-in. (10 x 15 cm) print.

Changing the flash settings



Press the flash button repeatedly to scroll through flash modes.




The current flash mode is shown in the LCD status area.

Flash modes	Flash fires	
 Auto Flash	When the lighting conditions require it.	
 Fill	Every time you take a picture, regardless of the lighting conditions. Use when the subject is in shadow or is “backlit” (when light is behind the subject). In low light, hold the camera steady or use a tripod.	
 Red-eye	If the Red-eye Pre-flash feature is turned off: <ul style="list-style-type: none"> ■ The flash fires once. ■ The camera then automatically corrects red-eye in the picture. 	If the Red-eye Pre-flash feature is turned on: <ul style="list-style-type: none"> ■ The flash fires once so the eyes become accustomed to the flash, then fires again when the picture is taken. ■ The camera then automatically corrects red-eye in the picture.
	To turn the Red-eye Pre-flash feature on/off, see Red Eye Preflash , page 34.	
 Off	Never	

For flash settings in each mode, see [page 51](#).



Picture-taking modes

Choose the mode that best suits your subjects and surroundings. (For flash ranges, see [page 50](#).)

Use this mode	For
 Auto AUTO	General picture-taking—offers an excellent balance of image quality and ease of use.
 Portrait	Full-frame portraits of people. Allows the subject to be sharp and the background to be indistinct. For best results, position your subject at least 6 ft (2 m) away and fill the frame with a head and shoulder pose. Use Telephoto to exaggerate background blur.
SCN Scene	Point-and-shoot simplicity when taking pictures under special conditions. (See Scene modes .)
 Video	Capturing video with sound. (See page 6 .)

Press a button to choose a mode.



Use this mode	For
 Landscape	Far-away scenes. The camera uses infinity auto-focus. Auto-focus framing marks are not available in Landscape.
 Close-up	Close range. Use available light instead of flash, if possible. The camera automatically sets the focus distance depending on the zoom position.



Press until the Close-up or Landscape icon appears in the LCD status area.











Scene modes

- 1 Press the Scene **SCN** button.
- 2 Press to display Scene mode descriptions.

NOTE: If the Help text turns off, press the OK button.

- 3 Press the OK button to choose a Scene mode.

Use this SCN mode	For	Camera pre-settings
Night Landscape	Distant scenery at night. Flash does not fire. Place the camera on a flat, steady surface or use a tripod.	Infinity Focus, Center-Weight Metering, Daylight White balance, Flash Off, maximum 2-second shutter speed
Night Portrait	Reduces red-eye of people in night scenes or low-light conditions. Place the camera on a flat, steady surface or use a tripod.	Multi-Pattern Exposure Metering, Multi-Zone Focus, Red-eye flash
Sport	Subjects that are in motion.	Fast shutter speed, Multi-Pattern Exposure Metering
Snow	Bright snow scenes.	Center-Weight Metering, Multi-Zone Focus, +1 Exposure Compensation
Beach	Bright beach scenes.	Center-Weight Metering, Daylight White Balance, +1 Exposure Compensation
Party	People indoors. Minimizes red-eye.	Multi-Pattern Exposure Metering, Multi-Zone Focus, Red-eye Flash
Self-Portrait	Close-ups of yourself. Assures proper focus and minimizes red-eye.	Macro Focus, Multi-Pattern Exposure Metering, Multi-Zone Focus, Red-eye Flash


Use this SCN mode		For	Camera pre-settings
	Manner/ Museum	Quiet occasions, like a wedding or lecture. Flash and sound are disabled.	No sounds, no flash, Multi-Pattern Exposure Metering, Multi-Zone Focus
	Fireworks	Flash does not fire. Place the camera on a flat, steady surface or use a tripod.	2-second exposure, Infinity Focus, Center-Weight Metering, Daylight White Balance
	Backlight	Subjects that are in shadow or “backlit” (when light is behind the subject).	Multi-Pattern Exposure Metering, Multi-Zone Focus, Fill-Flash
	Flower	Close-ups of flowers or other small subjects in bright light.	Macro Focus, Daylight White Balance, Center-Zone Focus, Center-Weight Metering
	Children	Action pictures of children in bright light.	Multi-Pattern Exposure Metering, Multi-Zone Focus
	Panning	Shooting a fast-moving subject. The background gives the sense of movement, while the subject appears still.	Shutter speed > 1/180 sec., Multi-Zone Focus, Multi-Pattern Exposure Metering
	Candlelight	Subjects illuminated by candlelight.	Multi-pattern Exposure Metering, Multi-Zone Focus, Daylight White Balance
	Sunset	Subjects at dusk.	Multi-pattern Exposure Metering, Multi-Zone Focus, Daylight White Balance
	Custom	Choosing your own settings.	Settings are saved, even after the camera is turned off. (To reset, see page 32.)
	Text	Documents.	Macro Focus, Center-Weight Metering, Multi-Zone Focus, +1 Exposure Compensation

Running a slide show

Use the Slide Show to display your pictures and videos (with sound).

NOTE: If you have an EasyShare photo frame dock 2, see [page 24](#).

Starting the slide show

- 1 Press the Review button, then press the Menu button.
- 2 Press $\blacktriangle/\blacktriangledown$ to highlight Slide Show , then press the OK button.
- 3 Press $\blacktriangle/\blacktriangledown$ to highlight Begin Show, then press the OK button.

Each picture and video is displayed once.

To interrupt the Slide Show, press the OK button.

Changing the slide show display interval

The default interval setting displays each picture for 5 seconds. You can set the display interval from 3 to 60 seconds.

- 1 On the Slide Show menu, press $\blacktriangle/\blacktriangledown$ to highlight Interval, then press the OK button.
- 2 Select a display interval.
To scroll through the seconds quickly, press and hold $\blacktriangle/\blacktriangledown$.
- 3 Press the OK button.

The interval setting remains until you change it.

Running a continuous slide show loop

When you turn on Loop, the slide show is continuously repeated.

- 1 On the Slide Show menu, press $\blacktriangle/\blacktriangledown$ to highlight Loop, then press the OK button.
- 2 Press $\blacktriangle/\blacktriangledown$ to highlight On, then press the OK button.


The slide show repeats until you press the OK button or until battery power is exhausted. The Loop feature remains until you change it.

Choosing a slide show transition

- 1 On the Slide Show menu, press $\blacktriangle/\blacktriangledown$ to highlight Transition, then press the OK button.
- 2 Press $\blacktriangle/\blacktriangledown$ to select a transition, then press the OK button.

Running a slide show with the EasyShare photo frame dock 2

Your package may include an EasyShare photo frame dock 2. (To purchase accessories, see www.kodak.com/go/v550accessories.)




Reviewing pictures and videos on a television

You can review pictures and videos on a television, computer monitor, or any device equipped with a video input. (Image quality on a television screen may not be as good as on a computer monitor or when printed.)

NOTE: Ensure that the Video Out setting (NTSC or PAL) is correct (see [Video Out](#), page 34).

- 1 Connect the audio/video cable (may be sold separately) from the camera A/V Out/USB port to the television video-in port (yellow) and audio-in port (white). See your television user's guide for details.
- 2 Review pictures and videos on the television.


Cropping pictures

- 1 Press the Review button.
- 2 Press ◀/▶ for previous/next.
- 3 Press the Menu button, choose Crop , then press the OK button.
- 4 Press Telephoto (T) to zoom in, or ◀/▶ ▲/▼ to move the crop box.
- 5 Follow the screen prompts.


NOTE: The picture is copied, then cropped. The original picture is saved.

- 6 Press the Menu button to exit the menu.

Making pictures from a video

- 1 Press the Review button.
- 2 Press ◀▶ to locate a video.
- 3 Press the Menu button, choose Make Picture , then press the OK button.
- 4 Follow the screen prompts.
NOTE: A picture is created. The original video is saved.
- 5 Press the Menu button to exit the menu.


Viewing picture/video information



To exit Review, press the Review button.

Using the histogram to view picture brightness


The histogram shows the distribution of the subject's brightness. If the peak is to the right of the graph, the subject is bright; if it's to the left, the subject is dark. Optimal exposure is achieved when the peak is in the middle of the histogram.



To turn on the histogram in Capture mode or in Review, press the LCD/Info button until the histogram appears.

Using exposure compensation to adjust picture brightness

You can adjust exposure compensation to make your pictures darker or lighter.



▶ to increase exposure compensation

◀ to decrease exposure compensation

Copying pictures and videos

You can copy pictures and videos from a card to internal memory or from internal memory to a card.

Before you copy, make sure that:

- A card is inserted in the camera.
- The camera's picture storage location is set to the location **from** which you are copying. See [Image Storage](#), page 32.

Copy pictures or videos:

- 1 Press the Review button, then press the Menu button.
- 2 Press $\blacktriangle/\blacktriangledown$ to highlight Copy $\blacktriangleright\blacktriangleright$, then press the OK button.
- 3 Press $\blacktriangle/\blacktriangledown$ to highlight an option.
- 4 Press the OK button.


NOTE: Pictures and videos are copied, not moved. To remove pictures videos and from the original location after copying, delete them (see [page 11](#)).




Tags that you applied for print, email, and favorites are not copied. Protection settings are not copied. To apply protection to a picture or video, see [page 11](#).



Changing picture-taking settings

You can change settings to get the best results from your camera. (Some settings are unavailable in some modes.)







- 1 Press the Menu button.
- 2 Press $\blacktriangle/\blacktriangledown$ to highlight a setting, then press the OK button.
- 3 Choose an option, then press the OK button.
- 4 Press the Menu button to exit.

Setting	Icon	Options
Self-timer A picture is taken 10 seconds after the Shutter button is pressed. (Place camera on a tripod or flat surface.)		Off (default) On Press the Shutter button halfway , then completely down. To cancel the Self-timer before the picture is taken, press the Self-timer button. (The Self-timer setting remains on.) Use the same procedure to take a self-timer video, but press the Shutter button completely down: NOTE: The video stops when no storage space remains.

Setting	Icon	Options
<p>Burst Camera takes up to 5 pictures (3 per second) while the Shutter button is pressed. Capture an expected event, such as a person swinging a golf club.</p>		<p>Off (default) On Press the Shutter button halfway, then hold it completely down to take pictures. <i>The camera stops taking pictures when you release the Shutter button, when the pictures are taken, or when there is no more storage space.</i> During quickview, you can delete all pictures in the burst series. To delete selectively, do so in Review (see page 11).</p>
<p>Picture Size Choose a picture resolution. <i>This setting remains until you change it.</i></p>		<p>5.0 MP (default)—for printing up to 20 x 30 in. (51 x 76 cm); pictures are highest resolution and largest file size. 4.4 MP (3:2)— ideal for printing 4 x 6 in. (10 x 15 cm) prints without cropping. Also for printing up to 20 x 30 in. (51 x 76 cm) 4.0 MP— for printing up to 20 x 30 in. (51 x 76 cm); pictures are medium resolution with smaller file size. 3.1 MP—for printing up to 11 x 14 in. (28 x 36 cm); pictures are medium resolution with smaller file size. 1.8 MP—for printing 4 x 6 in. (10 x 15 cm) prints, emailing, Internet, screen display, or for conserving space.</p>
<p>Video Size Choose a video resolution. <i>This setting remains until you change it.</i></p>		<p>640 x 480 (default) 320 x 240</p>




Setting	Icon	Options
<p>White Balance Choose your lighting condition. <i>This setting remains until you change modes or turn off the camera.</i></p>		<p>Auto (default)—automatically corrects white balance. Ideal for general picture taking. Daylight—for pictures in natural lighting. Tungsten—corrects the orange cast of household light bulbs. Ideal for indoor pictures under tungsten or halogen lighting without flash. Florescent—corrects the green cast of florescent lighting. Ideal for indoor pictures under florescent lighting without flash. Open Shade—for pictures in the shade in natural lighting. Available in Auto, Portrait, and SCN-Custom</p>
<p>ISO Speed Control the sensitivity of the camera sensor. <i>This setting remains until you change modes or turn off the camera.</i></p>	<p>ISO</p>	<p>Auto (default) ISO 80, 100, 200, 400 (800 available only in 1.8 MP picture quality.)</p>
<p>Color Mode Choose color tones. <i>This setting remains until you change modes or turn off the camera.</i></p>		<p>High Color Natural Color (default) Low Color Black & White Sepia—for pictures with a reddish-brown, antique look. NOTE: EasyShare software also lets you change a color picture to black-and-white or sepia. Unavailable in Video mode.</p>

Setting	Icon	Options
Sharpness Control picture sharpness. <i>This setting remains until you change it.</i>		High Normal (default) Low
Exposure Metering Evaluate light levels at specific areas of a scene. <i>This setting remains until you change modes or turn off the camera.</i>		Multi-pattern (default) —evaluates lighting conditions throughout the image to give an optimum picture exposure. Ideal for general picture taking. Center-weight —evaluates the lighting conditions of the subject centered in the viewfinder. Ideal for backlit subjects. Center-spot —similar to Center-weight, except the metering is concentrated on a smaller area of the subject centered in the viewfinder. Ideal when you need an exact exposure of a specific area in the picture.
AF Control Choose an auto-focus setting. <i>This setting remains until you change it.</i>		Continuous AF —because the camera is always focusing, there is no need to press the Shutter button halfway down to focus. Single AF (default) —uses external AF sensor and TTL-AF when the Shutter button is pressed halfway down. NOTE: In Video mode, the settings are Continuous AF or Off.
Focus Zone Select a large or concentrated area of focus. <i>This setting remains until you change it.</i>		Multi-zone (default) —evaluates 3 zones to give an even picture focus. Ideal for general picture taking. Center-zone —evaluates the small area centered in the viewfinder. Ideal when precise focus of a specific area in the picture is needed. NOTE: For the best pictures, the camera is set to Multi-zone when in Landscape mode.
Long Time Exposure Choose how long the shutter stays open.		0.5, 0.7, 1, 1.5, 2, 3, 4, 6, or 8 seconds

Setting	Icon	Options
<p>Set Album</p> <p>Choose Album names. <i>This setting remains until you change it. You can apply different Set Album choices to videos and to pictures.</i></p>		<p>Off (default) On</p> <p>Pre-select album names before you take pictures or videos. Then, all the pictures or videos you take are tagged with those album names. See page 35.</p>
<p>Image Storage</p> <p>Choose a storage location for pictures and videos. <i>This setting remains until you change it.</i></p>		<p>Auto (default)—the camera uses the card if one is in the camera. If not, the camera uses internal memory. Internal Memory—the camera always uses internal memory, even if a card is installed.</p>
<p>Reset to Default</p>		<p>All picture-taking settings return to their default. Available only in Scene Custom mode.</p>
<p>Video Length</p> <p>Choose video record length. <i>This setting remains until you change it.</i></p>		<p>Continuous (default) 5 sec. 15 sec. 30 sec.</p> <p>Available in Video mode.</p>
<p>Motion Image Stabilization</p> <p>Improve video stability.</p>		<p>On (default) Off</p> <p>Available in Video mode.</p>
<p>Setup Menu</p> <p>Choose additional settings.</p>		<p>See Customizing your camera.</p>


Customizing your camera

Use Setup to customize your camera settings.

- 1 In any mode, press the Menu button.
- 2 Press  to highlight Setup , then press the OK button.
- 3 Press  to highlight the setting you wish to change, then press the OK button.
- 4 Choose an option, then press the OK button.
- 5 Press the Menu button to exit.

Setting	Options
Camera Sounds Choose sound effects.	Theme —applies the same sound effect set to all functions. Individual —choose a sound effect for each function.
Sound Volume	Off Low (default) Medium High
LCD Brightness Choose inactivity time until LCD dims.	10 sec. 20 sec. (default) 30 sec. Continuous
Auto Power Off Choose inactivity time until camera turns off.	10 minutes (default) 5 minutes 3 minutes 1 minutes
Date & Time	See page 3 .

Setting	Options
<p>Video Out Choose the regional setting that lets you connect the camera to a television or other external device.</p>	<p>NTSC (default)—used in North America and Japan; most common format. PAL—used in Europe and China.</p>
<p>Photo Frame Choose EasyShare photo frame dock 2 settings.</p>	<p>Interval (between slide show frames) Loop (On/Off, for slide show) Transition (between slide show frames) Image Source (Auto/Internal/Favorites) Run Time (for slide show)</p>
<p>Orientation Sensor Orient pictures so that they are displayed with the correct side up.</p>	<p>On (default) Off On Transfer—sets Orientation Sensor on camera LCD to Off. When picture is transferred to the computer, it is rotated to the proper orientation.</p>
<p>Red Eye Preflash Choose if the Red-eye flash fires automatically before a picture is taken. NOTE: The camera automatically corrects red-eye, even if the Red Eye Preflash is set to Off.</p>	<p>On—red-eye flash fires before the picture is taken. Off (default)—camera removes red-eye automatically.</p>
<p>Date Stamp Imprint the date on pictures.</p>	<p>Choose a date option, or turn off the feature. (Default is off.)</p>
<p>Video Date Display Display Date/Time at the start of video playback.</p>	<p>On (default)— choose from date formats. Off</p>
<p>Video Print Nine frames are taken from each new video to make a 9-up picture.</p>	<p>On (default) Off</p>

Setting	Options
Blur Warning	On (default) Off (See page 7.)
Language	See page 3.
Format  CAUTION: Formatting deletes all pictures and videos, including those that are protected. Removing a card during formatting may damage the card.	Memory Card —deletes everything on the card; formats the card. Cancel —exits without making a change. Internal Memory —deletes everything in internal memory including email addresses, album names, and favorites; formats the internal memory.
About View camera information.	


Pre-tagging for album names

Use the Set Album (Still or Video) feature to pre-select album names before you take pictures or videos. Then, all the pictures or videos you take are tagged with those album names.

First—on your computer

Use the EasyShare software that came with your camera to create album names on your computer. Then copy up to 32 album names to the album name list the next time you connect the camera to the computer. See Kodak EasyShare software Help for details.

Second—on your camera

- 1 In any mode, press the Menu button.
- 2 Press ▲/▼ to highlight Set Album , then press the OK button.
- 3 Press ▲/▼ to highlight an album name, then press the OK button. Repeat to mark pictures or videos for albums.
Selected albums are noted with a check mark.
- 4 Highlight Exit, then press the OK button.
Your selections are saved. If you turn on the LCD, your album selection is displayed on the screen. A plus (+) after the album name means more than one album is selected.
- 5 Press the Menu button to exit the menu.

Third—transfer to your computer

When you transfer the tagged pictures or videos to your computer, EasyShare software opens and categorizes your pictures in the appropriate album. See EasyShare software Help for details.


Tagging pictures/videos for albums

Use the Album feature in Review mode to tag the pictures and videos in your camera with album names.

First—on your computer

Use Kodak EasyShare software to create album names on your computer, then copy up to 32 album names to the camera's internal memory.

Second—on your camera

- 1 Press the Review button, then locate the picture or video.
- 2 Press the Menu button.
- 3 Press ▲/▼ to highlight Album , then press the OK button.
- 4 Press ▲/▼ to highlight an album folder, then press the OK button.

To add other pictures to the same album, press ◀/▶ to scroll through the pictures. When the picture you want is displayed, press the OK button.

To add the pictures to more than one album, repeat step 4 for each album.

The album name appears with the picture. A plus (+) after the album name means the picture was added to more than one album.

To remove a selection, highlight an album name and press the OK button. To remove all album selections, select Clear All.

Third—transfer to your computer


When you transfer the tagged pictures and videos to your computer, EasyShare software opens and categorizes your pictures and videos in the appropriate album folder. See EasyShare software Help for details.

Sharing your pictures

Press the Share button to “tag” your pictures and videos. When they are transferred to your computer, you can share them. Press the Share button to tag pictures/videos:

- Any time. (The most recent picture/video taken is then displayed.)
- Just after you take a picture/video, during quickview (see [page 6](#)).
- After pressing the Review button (see [page 9](#)).

Tagging pictures for printing

- 1 Press the Share button. Press ◀/▶ to locate a picture.
- 2 Press ▲/▼ to highlight Print , then press the OK button.*
- 3 Press ▲/▼ to select the number of copies (0-99). Zero removes the tag for that picture.

The Print icon  appears in the status area. The default quantity is one.

- 4 **Optional:** You can apply a print quantity to other pictures. Press ◀/▶ to locate a picture. Keep the print quantity as is, or press ▲/▼ to change it. Repeat this step until the desired print quantity is applied to the pictures.
- 5 Press the OK button. Then press the Share button to exit the menu.

* To tag all pictures in the storage location, highlight Print All, press the OK button, then indicate the number of copies. Print All is not available in quickview. To remove print tagging for all pictures in the storage location, highlight Cancel Prints, then press the OK button. Cancel Prints is not available in quickview.

Printing tagged pictures

When you transfer the tagged pictures to your computer, the EasyShare software print screen opens. For details on printing, click the Help button in EasyShare software.

For more information on printing from your computer, printer dock, PictBridge enabled printer, or card, see [page 14](#).



NOTE: For the best 4 x 6 in. (10 x 15 cm) prints, use the 4.4 MP (3:2) picture quality. See [page 29](#).

Tagging pictures and videos for emailing

First—on your computer

Use Kodak EasyShare software to create an email address book on your computer. Then, copy up to 32 email addresses to the camera's internal memory. For details, click the Help button in EasyShare software.


Second—tag pictures/videos on your camera

- 1 Press the Share button. Press ◀/▶ to locate a picture/video.
- 2 Press ▲/▼ to highlight Email , then press the OK button.
The Email icon  appears in the status area.
- 3 Press ▲/▼ to highlight an email address, then press the OK button.

To tag other pictures/videos with the same address, press ◀/▶ to scroll through them. When the picture you want is displayed, press OK.

To send the pictures/videos to more than one address, repeat step 3 for each address.


Selected addresses are checked.

- 4 Press ▲/▼ to highlight Exit, then press the OK button.
The Email icon  appears in the status area.
- 5 Press the Share button to exit the menu.

Third—transfer and email

When you transfer the tagged pictures/videos to your computer, the Email screen opens and lets you send them to the addresses you specified. For details, click the Help button in EasyShare software.

Tagging pictures as favorites

You can preserve your favorite pictures in the Favorites  section of your camera's internal memory, then share them with friends and family.

NOTE: When you transfer pictures from your camera to your computer, all pictures (including favorites) are stored on your computer at full size. Favorite pictures - smaller copies of your originals - are loaded back to your camera, so you can share and enjoy more.

Share your favorite pictures in 3 easy steps:

1. Tag pictures as favorites	<ol style="list-style-type: none"> 1 Press the Share button. Press to locate a picture. 2 Press to highlight Favorite , then press the OK button. <i>The Favorite icon appears in the status area. To remove the tag, press the OK button again.</i>
2. Transfer pictures to your computer	<ol style="list-style-type: none"> 1 To enjoy full functionality, load and use the EasyShare software that was packaged with this camera. (See page 12.) 2 Connect the camera to the computer using the USB cable (see page 13) or an EasyShare dock. <i>The first time you transfer pictures, the software helps you make choices about your favorite pictures. Then, your pictures are transferred to the computer. Favorite pictures (smaller versions of the originals) are loaded to the Favorites section of your camera's internal memory.</i>
3. View favorites on your camera	<ol style="list-style-type: none"> 1 Slide the Auto/Favorites switch to Favorites . 2 Press to scroll through favorites.

NOTE: The camera holds a limited number of favorites. Use Camera Favorites in EasyShare software to customize the size of your camera Favorites section. Videos tagged as favorites remain in the Favorites folder in EasyShare software. For more information, click the Help button in EasyShare software.



Optional settings

In Favorites mode, press the Menu button to access optional settings.

	Slide Show (page 23)		Picture Information (page 26)
	Multi-up (page 10)		Remove all favorites (page 41)
			Setup Menu (page 32)

NOTE: Pictures taken at the 4.4 MP (3:2) picture quality are displayed at a 3:2 aspect ratio with a black bar at the top of the screen.

Removing all favorites from your camera

- 1 Slide the Auto/Favorites switch to Favorites .
- 2 Press the Menu button.
- 3 Highlight , then press the OK button.

All pictures stored in the Favorites section of internal memory are removed. Favorites are restored the next time you transfer pictures to the computer.






- 4 Press the Menu button to exit the menu.

Preventing favorites from transferring to the camera

- 1 Open EasyShare software. Click the My Collection tab.
- 2 Go to the Albums view.
- 3 Click the Camera Favorites Album for your camera.
- 4 Click Remove Album.

The next time you transfer pictures from your camera to the computer, use the Camera Favorites Wizard/Assistant in EasyShare software to either recreate your Camera Favorites Album or to turn off the Camera Favorites feature.

Tagging favorites for print and email

- 1 Slide the Auto/Favorites switch to Favorites . Press /  to locate a picture.
- 2 Press the Share button.
- 3 Highlight Print  or Email , then press the OK button.

NOTE: Favorites that were taken on this camera (not imported from another source) are good for prints up to 4 x 6 in. (10 x 15 cm).

5

Troubleshooting

Camera problems

Status	Solution
Camera does not turn on	<ul style="list-style-type: none"> ■ Make sure the correct battery type is installed (page 55). ■ Insert a new or charged battery.
Camera does not turn off and the lens does not retract	
Camera buttons and controls do not function	
Lens does not extend when the camera turns on or does not retract	<ul style="list-style-type: none"> ■ Make sure the battery is charged. ■ Turn the camera off, then on again. ■ Make sure the camera is not in Favorites mode. ■ If the problem still exists, get help (page 47).
In Review, a blue or black screen is displayed instead of a picture	<ul style="list-style-type: none"> ■ Transfer the picture to the computer. ■ Transfer <i>all</i> pictures to the computer (page 12). ■ Take another picture. If the problem continues, change the image storage location to internal memory (page 32).
Pictures remaining number does not decrease after taking a picture	<ul style="list-style-type: none"> ■ Continue taking pictures. The camera is operating normally. (The camera estimates the number of pictures remaining after each picture is taken, based on picture size and content.)
Picture orientation is not accurate	<ul style="list-style-type: none"> ■ Set the Orientation Sensor to ON (Orientation Sensor, page 34).

Status	Solution
Flash does not fire	<ul style="list-style-type: none"> ■ Check the flash setting, and change as needed (page 19). NOTE: The flash does not fire in all modes.
Storage location is almost or entirely full	<ul style="list-style-type: none"> ■ Transfer the pictures to the computer (page 12). ■ Delete pictures from the card or insert a new card. ■ Change the image storage location to internal memory (page 32).
Battery life is short	<ul style="list-style-type: none"> ■ Make sure the correct battery type is installed (page 55). ■ Wipe the contacts with a clean, dry cloth before inserting a battery in the camera. See page 55. ■ Insert a new or charged battery (page 1).
You cannot take a picture	<ul style="list-style-type: none"> ■ Turn the camera off, then on again. Make sure the camera is not in Favorites mode. ■ Depress the Shutter button all the way (page 5). ■ Insert a new or charged battery (page 1). ■ Wait until the Ready light turns green before taking another picture. ■ Memory is full. Transfer pictures to the computer (page 12), delete pictures (page 11), change image storage location, or insert another card.
Error message appears on the LCD	<ul style="list-style-type: none"> ■ Turn the camera off, then on again. ■ Remove the memory card. ■ Remove the battery. Wipe the contacts with a clean, dry cloth (page 55). ■ Insert a new or charged battery (page 1). ■ If the problem still exists, get help (page 47).
Memory card not recognized or the camera freezes with the card.	<ul style="list-style-type: none"> ■ Card may be corrupted. Format the card in the camera (Format, page 35). ■ Use another memory card.

Computer/connectivity problems

Status	Solution
Computer does not communicate with the camera	<ul style="list-style-type: none"> ■ Insert a charged battery (page 1). ■ Turn on the camera. ■ Make sure the USB cable is connected to the camera and the computer (page 13). (If using an EasyShare dock, check all cable connections. Make sure the camera is seated on the dock.) ■ Make sure the EasyShare software is installed (page 12).
Pictures do not transfer to the computer	<ul style="list-style-type: none"> ■ Click the Help button in EasyShare software.
Slide Show does not run on an external video device	<ul style="list-style-type: none"> ■ Adjust the camera Video Out setting (NTSC or PAL, Video Out, page 34). ■ Make sure the external device settings are correct. (See the device's user's guide).

Picture quality problems

Status	Solution
Picture is not clear	<ul style="list-style-type: none"> ■ To automatically set exposure and focus, press the Shutter button halfway. When the Ready light turns green, press the Shutter button completely down to take the picture. ■ Clean the lens (page 56). ■ Make sure the camera is not in Close-up mode if you are more than 21 in. (0.7 m) from your subject. ■ Place the camera on a flat, steady surface or use a tripod (especially in high-zoom settings or in low light).

Status	Solution
Picture is too dark or underexposed	<ul style="list-style-type: none"> ■ Reposition the camera for more available light. ■ Use Fill flash (page 19) or change your position so light is not behind the subject. ■ Move so that the distance between you and the subject is within the effective flash range (page 50). ■ To automatically set exposure and focus, press the Shutter button halfway. When the Ready light turns green, press the Shutter button completely down to take the picture.
Picture is too light	<ul style="list-style-type: none"> ■ Reposition the camera to reduce the amount of available light. ■ Turn the flash off (page 19). ■ Move so that the distance between you and the subject is within the effective flash range (page 50). ■ To automatically set exposure and focus, press the Shutter button halfway. When the Ready light turns green, press the Shutter button completely down to take the picture. ■ In Auto, Portrait, and SCN modes, adjust the exposure compensation (page 27).

Direct printing (PictBridge enabled printer) problems

Status	Solution
Cannot locate the desired picture	<ul style="list-style-type: none">■ Turn on the camera. Make sure the camera is not in Favorites mode.■ Use the Direct print menu to change the image storage location.
The Direct print menu interface turns off	<ul style="list-style-type: none">■ Press any camera button to redisplay the menu.
Cannot print pictures	<ul style="list-style-type: none">■ Make sure there is a connection between the camera and the printer (page 14).■ Make sure the printer and the camera have power.
Camera or printer display an error message	<ul style="list-style-type: none">■ Follow the prompts to resolve the issue.

6

Getting help

Helpful links

Camera

Get support for your product (FAQs, troubleshooting information, arrange for repairs, etc.)	www.kodak.com/go/v550support
Purchase camera accessories (camera docks, printer docks, lenses, cards, etc.)	www.kodak.com/go/v550accessories
Download the latest camera firmware and software	www.kodak.com/go/v550downloads
See online demonstrations of your camera	www.kodak.com/go/howto

Software

Get information on EasyShare software	www.kodak.com/go/easysw (or click the Help button in EasyShare software)
Get help with the Windows operating system and working with digital pictures	www.kodak.com/go/pcbasics

Other

Get support for cameras, software, accessories, more	www.kodak.com/go/support
Get information on Kodak EasyShare printer docks	www.kodak.com/go/printerdocks
Get information on Kodak inkjet products	www.kodak.com/go/inkjet
Optimize your printer for truer, more vibrant colors	www.kodak.com/go/onetouch
Register your camera	www.kodak.com/go/register

Telephone customer support

If you have questions concerning this product, you may speak with a customer support representative:

Australia	1800 147 701
Austria	0179 567 357
Belgium	02 713 14 45
Brazil	0800 150000
Canada	1 800 465 6325
China	800 820 6027
Denmark	3 848 71 30
Ireland	01 407 3054
Finland	0800 1 17056
France	01 55 1740 77
Germany	069 5007 0035
Greece	00800 44140775
Hong Kong	800 901 514
India	91 22 617 5823
Italy	02 696 33452
Japan	03 5540 9002
Korea	00798 631 0024

Netherlands	020 346 9372
New Zealand	0800 440 786
Norway	23 16 21 33
Philippines	1 800 1 888 9600
Poland	00800 4411625
Portugal	021 415 4125
Singapore	800 6363 036
Spain	91 749 76 53
Sweden	08 587 704 21
Switzerland	01 838 53 51
Taiwan	0800 096 868
Thailand	001 800 631 0017
Turkey	00800 448827073
United Kingdom	0870 243 0270
United States	1 800 235 6325
Outside the US	585 726 7260
International Toll Line	+44 131 458 6714
International Toll Fax	+44 131 458 6962

For the most up-to-date listings, visit:

www.kodak.com/US/en/digital/contacts/DAInternationalContacts.shtml

Camera specifications

For more specifications, visit www.kodak.com/go/v550support.

CCD—1/2.5 in. CCD, 4:3 aspect ratio

Output image size—

- 5.0 MP: 2576 x 1932 pixels
- 4.4 MP (3:2): 2576 x 1716 pixels
- 4.0 MP: 2304 x 1728 pixels
- 3.1 MP: 2048 x 1536 pixels
- 1.8 MP: 1552 x 1164 pixels

Color display—2.5 in. (4.6 cm) color hybrid LCD, 960 x 240 (230 K) pixels

Color electronic viewfinder—LCD

Preview (LCD)—Frame rate: 24 fps

Taking lens—3X optical zoom, aspheric all-glass Schneider-Kreuznach lens, f/2.8-4.8 (35 mm equivalent: 36-108 mm)

Lens protection—Built-in

Digital zoom—Combined zoom settings 3.2 to 12X in 0.2X increments. (Not supported for movie capture.)

Focus system—TTL-AF; auto, multi-zone, center-spot. Working range:

- 24 in. (60 cm)—infinity @ wide
- 24 in. (60 cm)—infinity @ telephoto
- 2–28 in. (5–70 cm) @ wide close-up
- 16–28 in (40–70 cm) @ telephoto close-up

Exposure metering—

- TTL-AE
- Multi-pattern, Center-spot, Center-weighted

Exposure compensation—+/-2.0 EV with 1/3 EV step

Shutter speed—Auto: 1/8–1/1400 sec. (1/2–8 sec. in long exposure mode)

ISO speed—

Auto: 80 to 160

Selectable: 80, 100, 200, 400, 800 (800 available only in 1.8 MP picture quality.)

Electronic flash—

Guide no. 5.6

Auto flash with photo sensor

Working range: 2–7.9 ft (0.6–2.4m) @ Wide; 2–5.2 ft (0.6–1.6m) @ Tele

Auto, Fill, Red-eye, Off

Capture modes—Auto, Portrait, SCN modes, Video.

Burst mode—Maximum 5 pictures @ 3 fps; AE, AF, AWB executed for first shot only

Video capture—


VGA (640 x 480) @ 30 fps

QVGA (320 x 240) @ 30 fps

Image file format—

Still: EXIF 2.21 (JPEG compression); file organization DCF

Video: QuickTime (CODEC MPEG4)

Image storage—Optional MMC or SD Card  (The SD logo is a trademark of the SD Card Association.)

Internal storage capacity—32 MB internal memory

Quickview—Yes

Video output—NTSC or PAL

Power—Kodak rechargeable Li-Ion battery

Communication with computer—USB 2.0 (full speed, PIMA 15740 protocol), via USB cable, EasyShare camera dock series 3, EasyShare printer dock series 3, photo frame dock 2

PictBridge support—Yes

Self-timer—10 seconds

Sound feedback—All On, Shutter Only, All Off

White balance—Auto, Daylight, Open Shade, Tungsten, Fluorescent

Auto sleep mode—Yes

Color modes—High Color, Natural Color, Low Color, Black & White, Sepia

Date stamp—None, YYYYMMDD, MMDDYYYY, DDMMYYYY

Tripod mount—1/4 inch

Operating temperature—32–104 F (0–40 C) degrees

Size—3.7 in. (94 mm) x 2.2 in. (56 mm) x 0.9 in. (22.1 mm) @ power off

Weight—5 oz (143 g) without card or battery

Flash settings in each mode

Capture modes	Default setting	Available settings
Auto	Auto*	Auto, Off, Fill Flash, Red-eye
Portrait	Auto*	Auto, Off, Fill Flash, Red-eye
Sport	Auto*	Auto, Off, Fill Flash, Red-eye
Children	Auto*	Auto, Off, Fill Flash, Red-eye
Party	Red-eye*	Auto, Off, Fill Flash, Red-eye
Beach	Auto*	Auto, Off, Fill Flash, Red-eye
Flower	Off	Off, Fill Flash
Fireworks	Off	Off

Capture modes	Default setting	Available settings
Snow	Auto*	Auto, Off, Fill Flash, Red-eye
Backlight	Fill	Fill
Close-up	Off	Off, Fill Flash
Night Portrait	Red-eye*	Auto, Off, Fill Flash, Red-eye
Landscape	Off	Off
Night Landscape	Off	Off
Manner/Museum	Off	Off
Text	Off	Fill, Off
Self-Portrait	Red-eye*	Auto, Off, Fill Flash, Red-eye
Panning	Off	Fill, Off
Candlelight	Off	Fill, Off
Sunset	Auto*	Auto, Off, Fill Flash, Red-eye
Custom	Auto	Auto, Off, Fill Flash, Red-eye
Video	Off	Off
Burst	Off	Off

* When you change to Auto or Red-eye in these modes, it becomes the default until you change it.

Storage capacities

File sizes vary. You may be able to store more or fewer pictures and videos. Favorites take up additional space in internal memory.

Picture storage capacity

	Number of pictures				
	5.0 MP	4.4 MP (3:2)	4.0 MP	3.1 MP	1.8 MP
32 MB internal memory	17	19	21	27	43
32 MB SD/MMC	19	22	24	30	48
64 MB SD/MMC	39	44	48	60	97
128 MB SD/MMC	79	88	97	121	195
256 MB SD/MMC	159	178	196	242	391
512 MB SD/MMC	319	356	392	485	783

Video storage capacity

	Minutes/seconds of video	
	VGA (640 x 480)	QVGA (320 x 240)
32 MB internal memory	48 sec.	2 min. 2 sec.
32 MB SD/MMC	53 sec.	2 min. 16 sec.
64 MB SD/MMC	1 min. 47 sec.	4 min. 32 sec.
128 MB SD/MMC	3 min. 34 sec.	9 min. 4 sec.
256 MB SD/MMC	7 min. 9 sec.	18 min. 9 sec.
512 MB SD/MMC	14 min. 19 sec.	36 min. 19 sec.

Important safety instructions



CAUTION:

Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel. Do not expose this product to liquid, moisture, or extreme temperatures. Kodak AC adapters and battery chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards. If the LCD breaks, do not touch the glass or liquid. Contact Kodak Support.

Using this product

- Read and follow these instructions before using Kodak products. Always follow basic safety procedures.
- The use of an accessory attachment that is not recommended by Kodak, such as an AC adapter, may cause fire, electric shock, or injury.
- If using this product in an airplane, observe all instructions of the airline.

Battery safety and handling



CAUTION:

When removing the battery, allow it to cool; it may be hot.

- Read and follow all warnings and instructions supplied by the battery manufacturer.
- Use only batteries that are approved for this product.
- Keep batteries out of the reach of children.
- Do not allow batteries to touch metal objects, including coins. Otherwise, a battery may short circuit, discharge energy, become hot, or leak.

- Do not disassemble, install backward, or expose batteries to liquid, moisture, fire, or extreme temperature.
- Remove the battery when the product is stored for an extended period of time. In the unlikely event that battery fluid leaks inside the product, contact Kodak Support.
- In the unlikely event that battery fluid leaks onto your skin, wash immediately with water and contact your local health provider. For additional health-related information, contact Kodak Support.
- Dispose of batteries according to local and national regulations.
- Do not charge non-rechargeable batteries.

For more information on batteries, see

www.kodak.com/global/en/service/batteries/batteryUsage.jhtml

Battery life

Li-Ion rechargeable battery: 120 pictures per charge. Battery life per CIPA testing method. (Approx. number of pictures in Auto mode, using 128 MB SD card.) Actual life may vary based on usage.

Extending battery life

- Limit the following activities that quickly deplete battery power:
 - Reviewing your pictures on the LCD (see [page 9](#))
 - Using the LCD as a viewfinder (see [page 5](#))
 - Excessive use of the flash
- Dirt on the battery contacts can affect battery life. Wipe the contacts with a clean, dry cloth before loading the battery in the camera.
- Battery performance is reduced at temperatures below 41° F (5° C). When using your camera in cold weather, carry spare batteries and keep them warm. Do not discard cold batteries that do not work; when they return to room temperature, they may be usable.

Power-saving features

If no action for	The camera	To turn it back on
1 minute	Screen turns off.	Press the OK button.
10, 5, 3 minutes	Enters auto power off.	Press a button or insert/remove card.

Upgrading your software and firmware

Download the latest versions of the software included on the Kodak EasyShare software CD and the camera firmware (the software that runs on the camera). See www.kodak.com/go/v550downloads.

Additional care and maintenance

- If the camera has been subjected to inclement weather or you suspect water has gotten inside the camera, turn off the camera and remove the battery and card. Allow all components to air-dry for at least 24 hours before using the camera again.
- Blow gently on the lens or LCD to remove dust and dirt. Wipe gently with a soft, lint-free cloth or an untreated lens-cleaning tissue. Do not use cleaning solutions unless designed specifically for camera lenses. Do not allow chemicals, such as suntan lotion, to contact painted surfaces.
- Service agreements may be available in your country. Contact a dealer of Kodak products for more information.
- For digital camera disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at www.eiae.org or the Kodak Web site at www.kodak.com/go/v550support.

Limited Warranty

Kodak warrants Kodak EasyShare digital cameras and accessories (excluding batteries) to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase.

Retain the original dated sales receipt. Proof of the date of purchase will be required with any request for warranty repair.

Limited warranty coverage

This limited warranty will be honored only within the geographical location that Kodak digital cameras and accessories were purchased.

Kodak will REPAIR or REPLACE Kodak EasyShare digital cameras and accessories if they fail to function properly during the warranty period, subject to any conditions and/or limitations stated herein. Such repair service will include all labor as well as any necessary adjustments and/or replacement parts. Such repair or replacement is the sole remedy under this warranty.

If replacement parts are used in making repairs, these parts may be remanufactured, or may contain remanufactured materials. If it is necessary to replace the entire product, it may be replaced with a remanufactured product.

Limitations

Request for Warranty service will not be accepted without proof of date of purchase, such as a copy of the original dated Kodak EasyShare digital camera or accessory sales receipt. (Always keep the original for your records.)

This warranty does not apply to the battery(s) used in digital cameras or accessories. This warranty does not cover circumstances beyond Kodak's control, nor problems caused by failure to follow the operating instructions in the Kodak EasyShare digital cameras and accessories User's Guides.

THIS WARRANTY DOES NOT APPLY WHEN FAILURE IS DUE TO SHIPPING DAMAGE, ACCIDENT, ALTERATION, MODIFICATION, UNAUTHORIZED SERVICE, MISUSE, ABUSE, USE WITH INCOMPATIBLE ACCESSORIES OR ATTACHMENTS, FAILURE TO

FOLLOW KODAK'S OPERATION, MAINTENANCE OR REPACKING INSTRUCTIONS, FAILURE TO USE ITEMS SUPPLIED BY KODAK (SUCH AS ADAPTERS AND CABLES), OR CLAIMS MADE AFTER THE DURATION OF THIS WARRANTY.

Kodak makes no other express or implied warranty for this product. In the event that the exclusion of any implied warranty is ineffective under the law, the duration of the implied warranty will be one year from the purchase date.

The option of replacement is Kodak's only obligation. Kodak will not be responsible for any special, consequential or incidental damages resulting from the sale, purchase, or use of this product, regardless of the cause. Liability for any special, consequential or incidental damages (including but not limited to loss of revenue or profit, downtime costs, loss of the use of the equipment, cost of substitute equipment, facilities or services, or claims of your customers for such damages resulting from the purchase, use or failure of the product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed and excluded herefrom.

Your rights

Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction.

Outside the United States and Canada

In countries other than the United States and Canada, the terms and conditions of this warranty may be different. Unless specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act.

Regulatory compliance

FCC compliance and advisory



Kodak EasyShare V550 zoom digital camera

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

Australian C-Tick



N137

Canadian DOC statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Class B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Waste Electrical and Electronic Equipment labeling



In the European Union, do not discard this product as unsorted municipal waste. Contact your local authorities or go to www.kodak.com/go/recycle for recycling program information.

VCCI Class B ITE

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づいたクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。取扱説明書に従って正しい取り扱いをして下さい。

English translation: This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

MPEG-4

Use of this product in any manner that complies with the MPEG-4 visual standard is prohibited, except for use by a consumer engaging in personal and non-commercial activities.

Index

A

- A/V out setting, 25
- A/V out, USB, ii
- about
 - picture, video, 26
 - this camera, 35
- AC adapter, 2
- accessories, 14
 - buying, 47
 - printer dock, 14
 - SD/MMC card, 4
- AF control, 31
- albums
 - set, 32
 - tagging pictures for, 35
- auto
 - focus control, 31
 - focus framing marks, 8
 - mode, 20
 - mode button, i
 - power off, 33
 - power-down, 56
- auto/favorites switch, ii

B

- B&W, 30
- backlight, 22
- battery
 - charging, 2
 - compartment, ii
 - expected life, 55
 - extending life, 55

- loading, 1
- lock, ii
- safety, 54
- types, 55

- beach, 21
- blur warning, 7, 35
- burst, 29
- button
 - auto mode, i
 - auto/favorites, ii
 - close-up/landscape, ii
 - delete, ii, 6
 - flash, i
 - LCD/Info, ii
 - menu, ii
 - OK, ii
 - on/off, i
 - portrait mode, i
 - review, ii, 9
 - SCN (scene) mode, i
 - share, ii
 - shutter, i
 - video mode, i
 - zoom, ii, 18

C

- cable
 - audio/video, 25
 - USB, 13
- camera screen (LCD)
 - reviewing pictures, videos, 9
- camera sounds, 33

- Canadian compliance, 60
- caring for your camera, 56
- charge battery, 2
- children, 22
- clock, setting, 3
- close-up mode, 20
- close-up/landscape button, ii
- color mode, 30
- compatibility, dock, 17
- computer
 - connecting camera, 12
 - transfer to, 12
- copy pictures
 - card to memory, 27
 - memory to card, 27
 - to computer via USB cable, 12
- cropping pictures, 25
- customer support, 48
- customizing camera settings, 33

D

- date setting, 3
- date stamp, 34
- DC-in, i
- delete button, ii
- deleting
 - during quickview, 6
 - from internal memory, 11
 - from SD/MMC card, 11
 - protecting pictures, videos, 11
- digital zoom, using, 18
- displaying slide show, 23
- disposal, recycling, 56
- dock

- connector, ii
 - photo frame 2, 2, 13, 24
 - printer, 14
- dock compatibility, 17
- downloading pictures, 12

E

- EasyShare photo frame dock 2, 2
- EasyShare software, 12
- emailing pictures, videos, 38
- exposure
 - compensation, 27
 - long time, 31
 - metering, 31
- external video device
 - viewing pictures, videos, 25

F

- favorites
 - removing, 41
 - settings, 40
 - tagging, 39
- favorites/auto switch, ii
- FCC compliance, 59
- fireworks, 22
- firmware, upgrading, 56
- flash
 - button, i
 - settings, 19
- flower, 22
- focus
 - framing marks, 8
 - zone, 31
- format, 35

H

help, 47
histogram, 27

I

icon
 blur, 7
icon, modes, 20
image storage, 32
information
 about pictures, videos, 26
installing
 battery, 1
 SD/MMC card, 4
 software, 12
internal memory capacity, 53
ISO speed, 30

K

Kodak EasyShare software
 installing, 12
 upgrading, 56
Kodak web sites, 47

L

landscape mode, 20
LCD, ii
 brightness, 33
LCD/Info button, ii
 using, 5
lens, i
 cleaning lens, 56
light sensor, i
loading
 battery, 1

SD/MMC card, 4
 software, 12
long time exposure, 31

M

Mac OS, installing software, 12
magnify picture, 9
maintenance, camera, 56
make picture from video, 26
manner/museum, 22
memory
 inserting card, 4
 storage capacities, 53
menu button, ii
microphone, i
modes, 20
 auto, 20
 backlight, 22
 beach, 21
 children, 22
 close-up, 20
 fireworks, 22
 flower, 22
 landscape, 20
 manner/museum, 22
 night landscape, 21
 night portrait, 21
 party, 21
 portrait, 20
 SCN (scene), 20
 self-portrait, 21
 snow, 21
 text, 22
 video, 20

motion image stabilization, 32

N

night landscape, 21

night portrait, 21

O

OK button, ii

on/off button, i

online prints, ordering, 16

optical zoom, 18

orientation sensor, 34

P

party, 21

photo frame dock 2, 2, 13, 24, 34

PictBridge printer, 14

picture quality, 29

picture size, 29

pictures

checking settings, 10

copying, 27

cropping, 25

deleting, 11

emailing tagged, 38

printing, 16

printing tagged, 38

protecting, 11

reviewing, 9

storage capacity, 53

tagging, 35

taking, modes, 20

transfer via USB cable, 12

portrait mode, 20

portrait mode button, i

power

auto off, 56

button, i

camera, 3

off, 33

printer dock, 14

printing

from a card, 16

from computer, 16

optimizing printer, 47

order online, 16

PictBridge, 14

tagged pictures, 16

with EasyShare printer dock, 14

protecting pictures, videos, 11

Q

quickview

using, 6

R

ready light, ii

recycling, disposal, 56

red-eye pre-flash, 34

regulatory information, 59

removing favorites, 41

repair, 47

reset to default, 32

review button, ii, 9

reviewing pictures

as you take them, 6

deleting, 11

LCD, 9

protecting, 11

- slide show, 23
- reviewing videos
 - deleting, 11
 - LCD, 9
 - protecting, 11
 - slide show, 23
- running slide show, 23

S

- safety, battery, 54
- SCN (scene) mode, i, 20
- SD/MMC card
 - inserting, 4
 - printing from, 16
 - slot, ii
 - storage capacities, 53
- self-portrait, 21
- self-timer, 28
- service and support telephone numbers, 48
- set album, 32
- setting
 - album, 32
 - auto focus, 31
 - auto power off, 33
 - blur warning, 35
 - camera sounds, 33
 - color mode, 30
 - date and time, 3
 - date stamp, 34
 - exposure metering, 31
 - focus zone, 31
 - image storage, 32
 - ISO, 30
 - long time exposure, 31
 - orientation sensor, 34
 - picture quality, 29
 - picture size, 29
 - picture taking mode, 20
 - sharpness, 31
 - sound volume, 33
 - video date display, 34
 - video out, 34
 - white balance, 30
- setup menu, 32
- shaking hand, 7
- Share button, ii
- sharpness, 31
- shutoff, auto, 56
- shutter
 - button, i
 - problems, 43
- sleep mode, 56
- slide show
 - continuous loop, 24
 - problems, 44
 - running, 23
- snow, 21
- software
 - installing, 12
 - upgrading, 56
- sound volume, 33
- sounds, 33
- speaker, ii
- specifications, camera, 49
- status
 - blur warning, 7
 - storage capacity, 53

strap, 1
strap post, ii
support, technical, 48

T

tagging

- favorites, 39
- for albums, 35
- for email, 38
- for print, 38

telephone support, 48

television, slide show, 25

text, 22

time, setting, 3

tips

- care & maintenance, 56

transfer, via USB cable, 12

trash can, deleting, 6

tripod socket, ii

turning camera on and off, 3

U

upgrading software, firmware, 56

URLs, Kodak web sites, 47

USB

- transferring pictures, 12

USB, A/V out, ii

V

VCCI compliance, 60

video

- checking settings, 10
- copying, 27
- date display, 34
- deleting, 11

- emailing tagged, 38

- length, 32

- mode, 20

- mode button, i

- out, 34

- print, 34

- protecting, 11

- reviewing, 9

- size, 29

- storage capacities, 53

- transfer to computer, 12

- viewing, 9

video/AF assist/self-timer light, i

viewfinder, i

viewing

- picture after taking, 6, 9

- picture, video information, 26

volume, 33

W

warranty, 57

white balance, 30

Windows OS, installing software, 12

Z

zoom

- digital, 18

- optical, 18

zoom button, ii