


HUAWEI Ascend P2

Quick Start Guide

Getting to know your phone

Welcome to the brand new world of your HUAWEI Ascend P2 smartphone! Before we begin, let's take a quick look at P2 and its external features.




Note: Use the power adapter and USB cable delivered with your phone.



Installing the micro-SIM card


Only micro-SIM cards are compatible with your P2. To purchase or replace a micro-SIM card, contact your service provider. Refer to the following figure to install a micro-SIM card. Once you install the micro-SIM card into your P2, you are ready to use P2. Press and hold the power button until P2 vibrates to power it on.



Using the buttons

From any screen, you can:

- Touch to return to the previous screen or close the current application if there are no previous screens.
- Touch to return to the home screen.
- Touch to display the option menu.
- Press the power button once to turn the screen on or off. Press and hold the power button for 10 seconds or more to restart your phone.
- Press the power and volume down buttons at the same time to take a screenshot.
- Press the camera button once to launch the camera. If your screen is locked, quickly press the camera button twice to launch the camera and take a photo. In the viewfinder, frame the scene you want to capture, and press the camera button to take the photo.



Unlocking the screen


The default theme is used as an example. Perform either of the following operations:

- To unlock the screen, drag down.
- To unlock the screen and open a preset application, drag towards the icon of the application.




Managing contacts

Touch to access **People**. If you are using your P2 for the first time, tap > **Manage contacts** to import contacts from a storage device to the phone. Touch the **Groups** tab to group your contacts for easier management.





Making a call



Touch to access **Phone**. Dial the phone number you wish to call or touch to choose someone from your contacts. You can also dial a phone number directly from a message, email, or web page by simply touching the number.






Taking a photo

Touch  to access **Camera**.
Your P2 features a BSI HD camera that lets you take photos in several modes, such as panoramic, beauty, and group.
To capture your most attractive smiles, your P2 provides face detection.
The camera automatically focuses on certain objects. To focus on a particular object, touch it on the viewfinder. Then, touch  to take a photo.


Recording a video

Touch  to access **Camera**, and switch to video mode.
Recording in 1080p full HD means stunning image quality and smooth video shots. Touch  to begin recording.



Viewing photos

Touch  to access **Gallery**.
Browse photos you have taken and relive those perfect moments.
To play your photos in a slideshow, choose an album and touch .
To edit a photo, touch  > **Edit**. You can then crop it, adjust its color, apply filters to it, and more.


Sending an email

Touch  to access **Email**.
Once you have set up your email accounts, you will be able to stay connected while on the go.

Listening to music

Touch  to access **Music**.
Your P2 features Dolby Digital Plus, which produces superior surround sound through the stereo earphones provided.
It makes high-pitched sounds clearer and low-pitched sounds more natural. In addition, the speaker is optimized to provide you with a supreme audio experience.
To turn on Dolby surround sound, touch .
Play your songs by name, artist, or album, and mark your favorite songs to add them to the **Favorites** list.

More information

Require additional assistance?
Touch  on your P2 to open **Help Center**.
Want to read the full user guide?
Visit <http://www.huaweidevice.com/worldwide> to download the HUAWEI Ascend P2 user guide.

All pictures and illustrations in this guide, including but not limited to the phone color, size, and display content, are for reference only. The actual product may vary. Nothing in this guide constitutes a warranty of any kind, express or implied.

For more information, please visit
<http://www.huaweidevice.com/worldwide>.

Model: HUAWEI P2-6011




31010MSE_02



Open the settings menu

View your photos





Open the settings menu

View your videos



Edit photos



Turn Dolby surround sound on or off

Mark the current song as a favorite and add it to your Favorites playlist