# **M** moto 360


# Charge your watch

Before using your Moto 360 Sport watch for the first time, remove the plastic cling from the back of the watch and **charge it for two hours** or until the charge level indicator shows 100%

Insert the micro USB connector cable in the charging dock, plug into a power outlet, and place your watch on the charging dock. Your watch works best with the Motorola Wireless Charging Dock (2nd Gen.). Always use the cable and wall charger that came with your watch.



Swipe down on the watch face to change the charging display screen color.



## Download & pair\*

- If you have an Android phone, download the Android Wear app from Google Play™ (tap Apps → Play Store). If you have an Apple iPhone device, download the Android Wear app from the Apple App Store.
- Open the Android Wear app on your phone and follow the prompts to pair your phone and watch over a Bluetooth® connection
- You can also stay connected over Wi-Fi\*\* when you leave your phone in another room or at work. To turn Wi-Fi on or off, swipe left on the watch face, then scroll down and tap Settings > Wi-Fi settings.
- \* Requires a phone running Android 4.3+ or IOS 8.2+.
- \*\* Not available for Apple iPhone.

## Android Wear

Use Android Wear on your phone to set up and manage your Moto 360 watch. You can disconnect the watch from your phone, pair with a new watch, find help, and more.

Change and customize watch faces:
Open the Android Wear phone app, scroll down to Watch Faces and tap MORE. Tap a watch face to select it. Tap to the watch face to customize elements like accent color, background color, and more. To design your own watch face, tap My Design\* and then tap to the selection of the

Assign apps to voice actions: You can use Google apps or other apps to perform specific voice actions on your watch.

In the Android Wear phone app, scroll down to **Jump into action with watch apps** and tap **MORE ACTIONS**. Select an action in the list, then select the app you want to use to perform the action.

\* Not available for Apple iPhone.

# Ready to go



Dim the screen: Press the power button or press your palm onto the screen until it vibrates. To turn on the screen, press the power button or tap the screen.

Adjust notifications: Swipe down from the top of the watch face. From there, swipe left to activate **theatre mode** (screen and notifications off). Keep swiping left to **boost screen brightness** or open the **Settings** menu.


#### Protect your device with Moto Care Accident Protection. Visit motorola.com/protectmydevice for more information. (U.S. only)



MOTOROLA and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC. Apple and iPhone are trademarks of Apple Inc., registered in the U.S. and other countries. All other product or service names are the property of their respective owners. © 2015 Motorola Mobility LLC. All rights reserved. Product ID: Moto 360 Sport Manual Number: 68018109001-A

motorola.com





# Moto Body

Moto Body tracks your fitness and activity levels. It gives you coaching advice when you want or need it, and helps you meet your goals for a healthier lifestyle.

Track steps, distance, calories burned, and heart activity against your goals, with useful notifications throughut the day.

To launch the app on your watch, swipe left on the watch face, then scroll down and tap Moto Body. Make sure your watch fits snug on your wrist to get an accurate heart rate measurement.

For a richer experience, get the Moto Body phone app\* for your Android phone on Google Play (tap Apps

→ Play Store). The phone app shows more details about your daily routine, and lets you sync your performance data with other fitness apps (see the Moto Body Running section).

\* Not available for Apple iPhone.

## Moto Body Running

Moto 360 Sport with built-in GPS lets you track your performance without having to carry your phone.



Moto Body Running tracks and records your time, pace, distance, and heart rate. You can review your running history and details any time.

Start a run: Swipe left on the watch face. then scroll down and tap Moto Body Running to launch the app. (Or you can just tap START on the Sport watch face). Tap Start run, select whether you want to run Indoors or Outdoors, select a goal, then tap Start .

During a run: Swipe left to see your heart rate zones and other running stats. Swipe right to Pause or End your run.

Use other fitness apps: You can sync your performance data with other fitness apps like Strava, MapMvRun, and Under Armour Record. Launch the Moto Body phone app\* on your phone, and follow the on-screen instructions to link your fitness app account with Moto Body.

## Tips & tricks

Location: When running outdoors, you need to activate GPS location and tracking features on your watch. To turn on, swipe left on the watch face, then scroll down and tap Settings → Location.

Always-on screen: This keeps the watch face dimly illuminated when not in use. It also keeps always-on apps (maps, fitness) running in ambient mode to optimize battery life. To turn on, swipe left on the watch face, then scroll down and tap Settings → Always-on screen.

AnyLight Display: Device displays can be hard to read in bright sunlight. Moto 360 Sport's hybrid display gives you great visibility under all light conditions. Indoors, the watch uses a bright LCD screen, Outdoors, reflective technology ensures you can read your watch whether you're running or enjoying other outdoor activities.

Change watch faces: Touch and hold the screen to see all your watch faces. Swipe left or right to find the watch face you want. Tap to customize the new watch face.

Live Dials: Some watch faces have Live Dials for important info at a glance (weather. daily steps).

To customize Live Dials.

tap when you select the watch face.

Notifications: Use touch gestures to view cards and select actions. Swipe up on a notification card to read it. Swipe up again for more cards, (if available). Swipe a notification:

- · left for details or actions
- · right to dismiss.
- · down to return to the home screen

Hands-free scrolling: Flick your wrist to flip through notifications. To activate wrist gestures, swipe left on the watch face. then scroll down and tap Settings → Wrist gestures.



# Voice commands

Just say "OK Google" to start using voice commands. You'll see a white screen with a red 8 icon.

Try a few commands like these:

- · "Remind me to send flowers to Ana."
- "What is my agenda for today?"
- "How tall is the Eiffel Tower?"
- · "Will it rain today?"
- "Wake me up in 30 minutes."
- · "Show me my steps."

To see a list of voice commands, swipe left three times from the watch face

Cleaning Your Watch: Wipe the watch with a soft damp cloth. Do not use solvents.

Tips & Tricks: For the full user's quide. tutorials, and helpful tips, visit www.motorola.com/mymoto360

Help: For help and more, open Android Wear on your phone and tap • → Help & feedback.


Help & more

Support: Visit us at www.motorola.com/support

Join the conversation: Talk, learn, and share with other Moto 360 users in our G Google+™ community at moto360community.com

News: Get the latest news, apps, tips. and much more-ioin us on:







IP67 Water Resistant: Your watch is not designed to work while submerged underwater. Do not use while swimming, or subject to pressurized streams of water.

<sup>\*</sup> Not available for Apple iPhone.