



ENGLISH

Quick start guide

LG-D855

4G LTE* ready

* Please check with your network operator if 4G LTE is available on your USIM

To download the latest full version of the user guide, go to www.lg.com on your PC or laptop.

Index


Overview	1
Setup	2
Screen.....	4
Call/Messaging.....	7
Smart Keyboard.....	8
Contacts	9
Google account.....	10
E-mail.....	10
Downloading applications.....	11
Internet/Maps	12
Camera & Video camera.....	13
Gesture Shot	14
QSlide	15
QuickMemo+.....	16

QuickRemote	17
Dual window	18
Connect your phone with your computer.....	19
Guidelines for safe and efficient use.....	20

NOTE:

- Always use genuine LG accessories. Failure to do this may void your warranty.
- Accessories may vary in different regions.
- Some features and service may vary by area, phone, carrier, plan and software version.
- Screen displays and illustrations on this Quick Start Guide may differ from those you see on actual phone.


Overview




Setup

Before you start using the phone, you need to insert the micro-USIM card.


Installing the micro-USIM card and battery




1. To remove the back cover, hold the phone firmly in one hand. With your other hand, lift off the back cover with your thumbnail as shown in figure below.



2. Slide the SIM card into the lower slot for the SIM card as shown in figure. Make sure the gold contact area on the card is facing downwards.




3. Insert the battery into place by aligning the gold contacts on the phone and the battery (1) and pressing it down until it clicks into place (2).



4. Align the back cover over the battery compartment (1) and press it down until it clicks into place.

TIP! Be careful to insert the micro-USIM card in the right place. It should be placed under the card slot.


Turning on the phone



Press and hold the **Power/Lock** key for a couple of seconds.


When you first turn on the phone, you will be guided through a series of essential steps to configure the phone settings.

Charging the phone



- The charging port is at the bottom of the phone.
- Insert one end of the charging cable into the phone and plug the other end into an electrical socket.
- To maximize the battery lifetime, ensure that the battery is fully charged before you use it for the first time.

Screen




Knock Code

The Knock Code feature allows you to tap the screen with your own Knock Code pattern using the screen divided by 4 squares to easily turn the screen on or off. You can disable this feature in the Lock screen settings.

1. From the Home screen, tap the **Apps Key > Settings > Display > Lock screen > Select screen lock > Knock Code**.
2. Tap the squares in a pattern to set your Knock Code.

Your Knock Code pattern can be 3 to 8 taps. Tap Done when you're finished.

NOTE: When the Knock Code is not in use, you can use Knock On function by tapping the screen.



Unlock the screen using the Knock Code


You can unlock the screen by tapping the Knock Code pattern you already set, when the screen turns off.

Home

You can customize each screen by adding widgets or shortcuts of your favourite applications.

Adding icons to the Home screen


- 1 Swipe your finger right or left to move through the screens. Stop when you get to a screen that you want to add items to.
- 2 Touch and hold an empty area in the Home screen. Touch the **Apps**, **Widgets** or **Wallpapers** option then select the item you want to add.

TIP! To delete a home screen application icon, touch and hold it, then drag it to the icon .

Screen

Unlock

After a period of inactivity, to conserve the battery, the screen you are currently viewing will be replaced by the lock screen.




Unlocking the screen

- 1 Press the **Power/Lock**  key.
- 2 Swipe the screen in any direction to unlock it.

Notification

On this screen, you can view and manage Sound, Wi-Fi, Bluetooth etc. The notification drawer runs across the top of the screen.



TIP! Touch **Edit**  and select items to be displayed on the notification drawer.


Call/Messaging

Making a call




1. Touch .
2. Dial the number you want to call or start typing the name of the contact by touching .


Answer a call

When you answer a call, swipe the  in any direction.




Sending a message

1. Touch  > .
2. In the **To** field, enter a number or touch  to select a number from **Call logs**, **Contacts**, **Favourites** or **Groups**.
3. Compose your message and touch **Send**.

NOTE: To answer an incoming, hold and slide  icon in any direction.

Smart Keyboard

Smart Keyboard recognizes your keyboard input habit and provide your own keyboard quickly inputting without errors.



Move cursor using space bar

Touch and hold the space bar and left or right to move the cursor.



Enter suggested word using gesture control


Enter text on the keyboard and the related word suggestions appear. Flick upward on the left to select the left-side suggestion. Flick upward on the right to select the right-side suggestion.

Contacts

You can automatically synchronize the contacts on the phone with any of your online address books, or even import contacts from another SIM card.

To import/export contacts, touch  > **Manage contacts** > **Import/Export**.

Creating a new contact




1. To create a new contact, touch  and enter the contact's information.
2. Touch **Add another field** to see more categories.
3. Touch **Save** to save the contact.

NOTE: To add a number from a recent call to your contacts, locate the number in your call log, touch the number. Touch **New contact** to create a new contact entry, or touch **update contacts** to add a new number to existing contacts.

Google account

The first time you open the Google application, you need to sign in. If you do not have a Google account, you will be prompted to create one.



Creating a Google account

1. Touch  >  > .
2. Touch **New** to start the Gmail setup wizard.
3. You then need to follow the setup instructions and enter the necessary information to activate the account. Please wait while the server creates your account.

E-mail

You can stay connected with MS Exchange and other popular email providers.




Setting up an account

1. Touch  > .
2. Select an email provider.
3. Enter your email address and password, then touch **Next**.
4. Follow the remaining instructions. When complete, touch Done to view your inbox.

Downloading applications

Download fun games and useful apps from the Play Store.

In home screen

1. Touch  > .
2. Sign in to your Google account.
3. Touch a category to browse selections, or touch  to search for an item.
4. Touch an app and follow the on-screen installation instructions. Once the app has been downloaded and installed, you will see a notification in the status bar.

Managing applications






Touch  >  > **General** > **Apps**.

You cannot uninstall the pre-installed applications.

Internet/Maps

Use the Web browser to surf the Net with ease. Use Maps during a journey to pinpoint your location and check for traffic updates on route.

Browsing the Web


1. Touch  > .
2. Touch the web address bar and enter an address, and then touch **Go**.
3. Scroll to navigate and touch links to open them. Touch the Menu key  to access additional settings.
4. To open a new browser tab, touch  > .

Setting up Maps


1. Touch  > .
2. Set up the connection to Wi-Fi or mobile data connection with GPS.

TIP! Use your index finger and thumb in a pinching or spreading motion to zoom in or out when using the Web browser, map or pictures. The use of these services and download content will generate additional costs. Charges for details, please consult your network operator.





Camera & Video camera



Gesture Shot



Take a picture with hand gesture.


1. Tap  >  >  >  or flicking the screen to switch to front camera.
2. Raise your hand until front camera detects it and a box appears on the screen.
3. Make a fist to take a photo.

TIP!

- Drag the beauty shot control bar at the bottom of the screen to make your skin brighter and softer when you take pictures of people including yourself with front camera.
- Hold your hand upright to make the front camera recognize it. It automatically displays the guide box on your hand.

QSlide

From any screen, bring up a notepad, calendar, and more as a window inside your screen.



1		Tap to exit the QSlide and return to full window.
2		Tap to adjust transparency.
3		Tap to end the QSlide.
4		Tap to adjust the size.

NOTE: QSlide can be supported up to two windows at the same time.


1. Touch and slide the status bar downwards > tap QSlide apps or while using applications that support QSlide, tap . The function will be continuously displayed as a small window on your screen.
2. You can make a call, browse the Web, or choose other phone options. You can also use and tap the screen under the small windows when the transparency bar is not full






QuickMemo+

The **QuickMemo+** allows you to create memos and capture screen shots.



Capture screens, draw on them and share them with family and friends with QuickMemo+.








1. (While screen is switched off)
Press and hold the Volume Up key. Or touch and slide the status bar downward and tap .
2. Select the desired menu option from **Pen type, Colour, Eraser** and create a memo.
3. Tap  in the Edit menu to save the memo with the current screen. To exit QuickMemo+ at any time, tap .

QuickRemote

QuickRemote turns your phone into a Universal Remote for your home TV, Set top box, audio system.



1. Touch and slide the status bar downwards and tap  > **ADD REMOTE**. Or Tap  >  > **Apps** tab >  **QuickRemote** > tap .


2. Select the type and brand of device, then follow the on-screen instructions to configure the device(s).

3. Touch and slide the status bar downwards and use QuickRemote functions.

Dual window

The two split-screen can be viewed at the same time.

1. Touch and hold the Back button to split the screen.
2. Tap or drag app icon you want to use.



 : Switch two screens.

 : View app list.

 : Change to full screen.

 : Close most recent app.

NOTE: The Dual Window should be set before you use the function.

1. Tap  >  > **Apps** tab >  **Settings** > **General** tab > **Dual window**.
2. Tap the **Dual window** switch to toggle it **On** or **Off**.

Connect your phone with your computer

By connecting your phone to a PC, you can transfer data directly by using PC software program (LG PC Suite).

Sync your phone with your computer

To synchronize your phone with your PC using the USB cable, you need to install PC software (LG PC Suite) onto your PC. Download the program from the LG website (www.lg.com).

1. Use the USB data cable to connect your phone to the PC.
2. **USB connection type** list will appear, and select **Media device (MTP)**.
3. Run the LG PC Suite program from your PC.
Refer to the PC software (LG PC Suite) help for more information.

Guidelines for safe and efficient use

Please read these simple guidelines.

Not following these guidelines may be dangerous or illegal.

Should a fault occur, a software tool is built into your device that will gather a fault log.

This tool gathers only data specific to the fault, such as signal strength, cell ID position in sudden call drop and applications loaded.

The log is used only to help determine the cause of the fault. These logs are encrypted and can only be accessed by an authorized LG Repair centre should you need to return your device for repair.

Exposure to radio frequency energy

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) recommended by international guidelines (ICNIRP). These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population.

The guidelines were developed by independent scientific organisations through periodic and thorough evaluation of

scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit stated in the international guidelines is 2.0 W/kg*. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR of the device while

operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the device.

Before a phone model is available for sale to the public, compliance with the European R&TTE directive must be shown. This directive includes as one essential requirement the protection of the health and the safety for the user and any other person. The highest SAR value for this device when tested for use at the ear is 0.291 W/kg.

Guidelines for safe and efficient use

This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 1.5 cm away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the product at least 1.5 cm away from your body. In order to transmit data files or messages, this device requires a quality connection to the network. In some cases, transmission of data files or messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

The highest SAR value for this device when

tested for use at the body is 0.269 W/kg.

* The SAR limit for mobile devices used by the public is 2.0 watts/ kilogram (W/kg) averaged over ten grams of body tissue. The guidelines incorporate a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

SAR values may vary depending on national reporting requirements and the network band.

FCC SAR information

Your mobile device is also designed to meet the requirements for exposure to

radio waves established by the Federal Communications Commission (USA) and Industry Canada.

These requirements set a SAR limit of 1.6 W/kg averaged over 1 gram of tissue. The highest SAR value reported under this standard during product certification for use at the ear is 0.39 W/kg and when properly worn on the body is 0.76 W/kg.

Additionally, this device was tested for typical body-worn operations with the back of the phone kept 1cm (0.39 inches) between the users body and the back of the phone.

To comply with FCC RF exposure requirements, a minimum separation

distance of 1cm (0.39 inches) must be maintained between the user's body and the back of the phone.

*** FCC Notice & Caution**

Notice!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Guidelines for safe and efficient use

Caution!

Change or Modifications that are not specifically approved by the manufacturer could void the user's authority to operate the equipment.

Product care and maintenance

 **WARNING!** Only use batteries, chargers and accessories approved for use with this particular phone model. The use of any other types may invalidate any approval or warranty applying to the phone and may be dangerous.

- Do not disassemble this unit. Take it to a qualified service technician when repair work is required.

- Repairs under warranty, at LG's discretion, may include replacement parts or boards that are either new or reconditioned, provided that they have functionality equal to that of the parts being replaced.
- Keep away from electrical appliances such as TVs, radios and personal computers.
- The unit should be kept away from heat sources such as radiators or cookers.
- Do not drop.
- Do not subject this unit to mechanical vibration or shock.
- Switch off the phone in any area where you are required to by special regulations. For example, do not use your phone in

hospitals as it may affect sensitive medical equipment.

- Do not handle the phone with wet hands while it is being charged. It may cause an electric shock and can seriously damage your phone.
- Do not charge a handset near flammable material as the handset can become hot and create a fire hazard.
- Use a dry cloth to clean the exterior of the unit (do not use solvents such as benzene, thinner or alcohol).
- Do not charge the phone when it is on soft furnishings.
- The phone should be charged in a well

ventilated area.

- Do not subject this unit to excessive smoke or dust.
- Do not keep the phone next to credit cards or transport tickets; it can affect the information on the magnetic strips.
- Do not tap the screen with a sharp object as it may damage the phone.
- Do not expose the phone to liquid or moisture.
- Use accessories like earphones cautiously. Do not touch the antenna unnecessarily.
- Do not use, touch or attempt to remove or fix broken, chipped or cracked glass. Damage to the glass display due to

Guidelines for safe and efficient use

- abuse or misuse is not covered under the warranty.
- Your phone is an electronic device that generates heat during normal operation. Extremely prolonged, direct skin contact in the absence of adequate ventilation may result in discomfort or minor burns. Therefore, use care when handling your phone during or immediately after operation.
 - If your phone gets wet, immediately unplug it to dry off completely. Do not attempt to accelerate the drying process with an external heating source, such as an oven, microwave or hair dryer.
 - The liquid in your wet phone, changes the color of the product label inside your phone. Damage to your device as a result of exposure to liquid is not covered under your warranty.

Efficient phone operation

Electronics devices

All mobile phones may receive interference, which could affect performance.

- Do not use your mobile phone near medical equipment without requesting permission. Avoid placing the phone over pacemakers, for example, in your breast pocket. Please consult your doctor

to determine if operation of your phone may interfere with the operation of your medical device.

- Some hearing aids might be disturbed by mobile phones.
- Minor interference may affect TVs, radios, PCs etc.
- Use your phone in temperatures between 0 °C and 40 °C, if possible. Exposing your phone to extremely low or high temperatures may result in damage, malfunction, or even explosion.

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 15cm be maintained between a mobile phone and a pacemaker to avoid potential interference with the pacemaker. To achieve this use the phone on the opposite ear to your pacemaker and do not carry it in a breast pocket.

Hospitals

Switch off your wireless device when requested to do so in hospitals, clinics or health care facilities. These requests are designed to prevent possible interference with sensitive medical equipment.

Guidelines for safe and efficient use

Road safety

Check the laws and regulations on the use of mobile phones in the area when you drive.

- Do not use a hand-held phone while driving.
- Give full attention to driving.
- Pull off the road and park before making or answering a call if driving conditions so require.
- RF energy may affect some electronic systems in your vehicle such as car stereos and safety equipment.
- When your vehicle is equipped with an

air bag, do not obstruct with installed or portable wireless equipment. It can cause the air bag to fail or cause serious injury due to improper performance.

- If you are listening to music whilst out and about, please ensure that the volume is at a reasonable level so that you are aware of your surroundings. This is of particular importance when near roads.

Avoid damage to your hearing



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Damage to your hearing can occur if you are exposed to loud sound for long periods of

time. We therefore recommend that you do not turn on or off the handset close to your ear. We also recommend that music and call volumes are set to a reasonable level.

- When using headphones, turn the volume down if you cannot hear the people speaking near you, or if the person sitting next to you can hear what you are listening to.

NOTE: Excessive sound pressure from earphones and headphones can cause hearing loss.

Glass Parts

Some parts of your mobile device are made of glass. This glass could break if your

mobile device is dropped on a hard surface or receives a substantial impact. If the glass breaks, do not touch or attempt to remove it. Stop using your mobile device until the glass is replaced by an authorised service provider.

Blasting area

Do not use the phone where blasting is in progress. Observe restrictions and follow any regulations or rules.

Potentially explosive atmospheres

- Do not use your phone at a refueling point.
- Do not use near fuel or chemicals.

Guidelines for safe and efficient use

- Do not transport or store flammable gas, liquid or explosives in the same compartment of your vehicle as your mobile phone or accessories.

In aircraft

Wireless devices can cause interference in aircraft.

- Turn your mobile phone off before boarding any aircraft.
- Do not use it on the ground without permission from the crew.

Children

Keep the phone in a safe place out of the reach of small children. It includes small parts which may cause a choking hazard if detached.

Emergency calls

Emergency calls may not be available on all mobile networks. Therefore you should never depend solely on your phone for emergency calls. Check with your local service provider.

Battery information and care

- You do not need to completely discharge the battery before recharging. Unlike

other battery systems, there is no memory effect that could compromise the battery's performance.

- Use only LG batteries and chargers. LG chargers are designed to maximize the battery life.
- Do not disassemble or short-circuit the battery.
- Keep the metal contacts of the battery clean.
- Replace the battery when it no longer provides acceptable performance. The battery pack may be recharged hundreds of times before it needs replacing.
- Recharge the battery if it has not been

used for a long time to maximize usability.

- Do not expose the battery charger to direct sunlight or use it in high humidity, such as in the bathroom.
- Do not leave the battery in hot or cold places, as this may deteriorate battery performance.
- There is risk of explosion if the battery is replaced with an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions. Please recycle when possible. Do not dispose as household waste.
- If you need to replace the battery, take it to the nearest authorised LG Electronics

Guidelines for safe and efficient use

service point or dealer for assistance.

- Always unplug the charger from the wall socket after the phone is fully charged to save unnecessary power consumption of the charger.
- Actual battery life will depend on network configuration, product settings, usage patterns, battery and environmental conditions.
- Make sure that no sharp-edged items such as animal's teeth or nails, come into contact with the battery. This could cause a fire.

Instructions for Wireless Charger

Be sure to use a wireless charger that is genuine or compatibility-certified (by WPC Qi standards).

(Wireless charger is sold separately.)

DECLARATION OF CONFORMITY

Hereby, **LG Electronics** declares that this **LG-D855** product is in compliance with the essential requirements and other relevant provisions of Directive **1999/5/EC**. A copy of the Declaration of Conformity can be found at **<http://www.lg.com/global/declaration>**

Notice: Open Source Software

To obtain the corresponding source code under GPL, LGPL, MPL and other open source licences, please visit <http://opensource.lge.com/>

All referred licence terms, disclaimers and notices are available for download with the source code.

Contact office for compliance of this product:

LG Electronics Inc.
EU Representative, Krijgsman 1,
1186 DM Amstelveen, The Netherlands

NOTE:

- Screen displays and illustrations may differ from those you see on actual phone.
- Some of the contents in this guide may differ from your phone depending on the software of the phone or your service provider. All information in this document is subject to change without notice.
- Always use genuine LG accessories. Failure to do this may void your warranty.
- Available accessories may vary depending on your region, country or service provider.
- Some features and service may vary by region, phone, service provider and software version.

Guidelines for safe and efficient use

Laser safety statement

Caution!

This product employs a Laser system. To ensure proper use of this product, please read this owner's manual carefully and retain for future reference. Should the unit require maintenance, contact an authorized service center.

Use of controls, adjustments, or the performance of procedures other than those specified herein may result in hazardous radiation exposure.

To prevent direct exposure to laser beam, do not try to open the enclosure or to make the direct contact with the laser.

CLASS 1	LASER PRODUCT
KLASSE 1	LASER PRODUKT
LUOKAN 1	LASER LAITE
KLASS 1	LASER APPARAT
CLASSE 1	PRODUIT LASER



Disposal of your old appliance

- 1** All electrical and electronic products should be disposed of separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 2** The correct disposal of your old appliance will help prevent potential negative consequences for the environment and human health.
- 3** For more detailed information about disposal of your old appliance, please contact your city office, waste disposal service or the shop where you purchased the product.



Disposal of waste batteries/accumulators

- 1** This symbol may be combined with chemical symbols for mercury (Hg), cadmium (Cd) or lead (Pb) if the battery contains more than 0.0005% of mercury, 0.002% of cadmium or 0.004% of lead.
- 2** All batteries/accumulators should be disposed separately from the municipal waste stream via designated collection facilities appointed by the government or the local authorities.
- 3** The correct disposal of your old batteries/accumulators will help to prevent potential negative consequences for the environment, animal and human health.
- 4** For more detailed information about disposal of your old batteries/accumulators, please contact your city office, waste disposal service or the shop where you purchased the product.

Expected Battery Life is 6 months. Gradual reduction in battery capacity is a manifestation of natural wear and cannot be considered a fault within the meaning of the Civil Code.